* Revised 8/4/2019

GAME CLOCK INSTRUCTIONS

TURNING THE CLOCK ON

1. Plug in the scoreboard connector under the counter to turn off the digital clock on the scoreboard.
2. Turn the scoreboard console on; the switch is on the back of the control board.
3. The display on the screen will ask, “RESUME GAME? Y/N” Press the **CLEAR** button to start a new game.
4. When “Select Code” appears, choose **ENTER** to accept the current code or change the code by typing the 4-digit code and pressing **ENTER**.
   - Use code **4401** if you DO NOT want to track Shots on Goal (SOG) on the rink scoreboard.
   - Use code **4402** if you want to track SOG on the rink scoreboard.
5. Press the **CLEAR** button when prompted for tenths of a second.

SETTING THE CLOCK

1. Press the **SET MAIN CLOCK** button.
2. Type in the time and press **ENTER**. Example: If warm-ups are 5 minutes, enter 500 and hit ENTER.
   - If needed, you can press **CLEAR** twice to clear clock changes and return to the game.
3. The period will default to 1, so you do not need to set the period to start the game. After the first period, press the **PERIOD +** button once to change to the next period.
4. To run the clock, press the **START** button. To stop the clock, press the **STOP** button.
5. To reset the time after warm-ups or after a period, press **SET MAIN CLOCK** and follow step 2 to set the time.
6. **Adjusting the Main Clock in the middle of a period:** If a referee instructs you to adjust the main clock during a period and any penalties are in progress, a message will appear “ADJUST PENALTY TIMERS Y/N? Please ENTER to adjust all penalty timers to the correct time based on the new time entered for the main clock, or press CLEAR to not change the penalty timers. For example, if the referee asks you to add 8 seconds back on the main clock because the clock was running when it shouldn’t have been, you will choose ENTER for yes to adjust the penalty timers along with the adjustment to the main clock.

SCORING OR CORRECTING A GOAL

1. Press **SCORE +** or **SCORE -** to increase or decrease the score for the Home team or Guest team.

ENTERING PENALTIES

1. Press the **PLAYER PENALTY •** button.
2. Type in the **player’s jersey number** and press **ENTER**.
3. The **penalty time** will default to 2:00 minutes.
   - If the penalty is a 2:00 minute penalty, then just press **ENTER**.
   - If the penalty time is different than 2:00, then type in the **penalty time** and press **ENTER**.

EDITING PENALTIES

1. Press the **PLAYER PENALTY •** button.
2. Press the **UP ARROW** key until the penalty you need to edit shows on the display (check player number and time remaining to make sure you have the correct one if there are multiple penalties on the clock).
3. Press **ENTER** once you have found the penalty you want to edit.
4. Type in the **player's jersey number** and press **ENTER**.
5. Type in the **penalty time** and press **ENTER**.

REMOVING PENALTIES

1. If you are removing a penalty and it is the only penalty on the scoreboard for that team,
   - Press **CLEAR ALL PENALTIES** and then press **ENTER**.
2. If you are removing a penalty and there are multiple penalties in progress on the scoreboard for that team,
   - Press the **DELETE PENALTY •** button.
   - Press the **UP ARROW** key until the penalty you need to remove shows on the display (check player number and time remaining to make sure you have the correct one if there are multiple penalties on the clock).
   - Press **ENTER**.

EDITING THE PERIOD

1. If the scoreboard displays a period number greater than the current period, press **EDIT** and then press **PERIOD +1**.
2. Enter the correct period value using the number pad and then press **ENTER**.

RECORDING SHOTS ON GOAL (SOG) – if applicable game code was used

1. Press **SHOTS ON GOAL +1** or **SHOTS ON GOAL -1** to register or remove a shot for the Home team or Guest team.

AFTER GAME

1. Turn the scoreboard console off.
2. Unplug the scoreboard under the counter to display the regular digital clock.